

# INDASH <sup>by</sup> PANAVISE®

I-75102-600

Page 1 of 1

## MOUNTING LOCATION:

Right side of radio

## TOOLS REQUIRED:

- 8mm nut driver
- (4) Radio removal tools (DIN)
- Clean shop rag

## HARDWARE INCLUDED:

None

## CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75102-600**  
MFG: **AUDI**  
MODELS & YEARS:  
**A4 1998-2001, S4 2000-02**  
**A6 1998-2004, Allroad 2001-05**  
[Excluding A4 99.5]

## \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1** With the Audi Radio removal tools (4 each) (DIN) remove the radio and place it on the rag over the console. **DO NOT** disconnect the wires from the radio.

**STEP #2** With the 8mm nut driver, remove one screw from the right bottom corner of the radio cavity that holds the climate control in place. Place the hole of the InDash Mount over the screw hole, align the holes and reinstall the screw. Install the radio back into place.

**STEP #3** Attach the phone holder to your InDash Mount.

INSTALLATION IS NOW COMPLETE.  
ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Mounting Screw



Finished Installation Pictures



04-06-05