

MOUNTING LOCATION: CELL PHONE & MEDIA MOUNT
Right side of radio
INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

- 8mm nut driver
- Radio removal tool
(Slide, HVAC Control)
- #A 000 833 03 61

PART#: 75102-196
MFG: AUDI
MODELS & YEARS:
A4 96-97

HARDWARE INCLUDED:

None

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 Remove the radio, this is done by inserting the radio removal tool and pulling straight out. Once the radio is released, pull the tool out of the radio and place a cloth over the shifter and set the radio on that cloth.

NOTE: The radio removal tool used was from Mercedes. This tool is available at the Mercedes dealerships and is called "Slide, HVAC Control #A 000 833 03 61"

STEP #2 Remove one screw located in the upper right corner of the radio cavity. Place the InDash Mount over that screw hole and reinstall the screw. If InDash is positioned properly, the part number will be readable from left to right.

STEP #3 Take the radio and push it back into place, push enough to make sure it locks securely.

STEP #4 Install the phone holder on the InDash Mount. If using a PortaGrip #701, adjust to the size of the phone prior to installing.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



The unit pictured is our handmade prototype model, not a production part. **This photo is for location reference only.**

