

INDASH by PANAVISE®

I-75102-705

Page 1 of 1

MOUNTING LOCATION:

Right side of climate control CR

TOOLS REQUIRED:

Hook tool

8mm or 5/16 wrench

Soft cloth

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75102-705

MFG: AUDI

MODELS & YEARS: A6 2005-2007

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.


STEP#1: With hook tool, remove the climate control section only by inserting the hook tool into upper right or left of climate control by the Auto buttons. Pull to release (2) clips on that side (upper and lower). Repeat on the other side.

STEP#2: Place soft cloth on the console to protect it from scratches. Set climate control on the cloth. remove (1) bolt with 5/16-8mm wrench. Slide InDash by PanaVise Mount in behind the bracket that the screw was removed from. Reinstall the screw.

STEP#3: Reinstall the climate control.

INSTALLATION IS NOW COMPLETE.

ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Mounting screw location



Prototype InDash installed showing location



11-21-06