

### MOUNTING LOCATION:

Right side of radio JR

### TOOLS REQUIRED:

- #2 Phillips screwdriver
- 5/64 Drill bit and drill
- DIN radio removal tools

### HARDWARE INCLUDED:

(2)G-#6x1/2"Flat Head SheetMetal Screw

### CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75102-399**

MFG: **AUDI**

MODELS & YEARS:

**A8 97-2003**

**A8L 2001-03**

**S8 2001-03**

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

**STEP #1** With the radio removal tools remove the radio by inserting the tools in the radio slots located at the bottom corners of the radio. Pull radio out and set it on the left side of the console. **DO NOT** disconnect the wires.

**STEP #2** 1997-1999 MODELS: On the right side of the radio cavity locate a small step approximately 1/4" high. Place the InDash Mount with the countersunk holes against the step and mark the (2) holes. Remove InDash and carefully drill the (2) 5/64 pilot holes. [NOTE: It is a very tight fit so the holes must be drilled as accurate as possible to match the InDash holes.] Once the pilot holes have been drilled take the InDash Mount and place it over the pilot holes and carefully secure with the (2) #6 X 1/2 screws provided.

2000-2003 MODELS: Pull off bezel containing emergency switches and surrounding the radio and climate control by pulling on sides straight out from radio cavity; then carefully angle out. Disconnect the wires and set aside. Be sure to mount InDash just above the pinch clasp. See picture below. Place the InDash Mount with the countersunk holes against the step and mark the (2) lower holes. Top hole will be covered. Remove InDash and carefully drill the (2) 5/64 pilot holes. [NOTE: It is a very tight fit so the holes must be drilled as accurate as possible to match the InDash holes.] Once the pilot holes have been drilled take the InDash Mount and place it over the pilot holes and carefully secure with the (2) #6 X 1/2 screws provided.

**STEP #3** Install the radio back in place and push it until it clips into position.

**INSTALLATION IS NOW COMPLETE.  
ENJOY YOUR NEW PANAVISE INDASH MOUNT.**



1998-99 A8 Location



Hole locations to drill on 2000 A8. Use extreme care in drilling holes.

Drill 2places



00-03 S8,A8 & A8L Location



10-27-05