

INDASH by PANAM

I-75102-500

Page 1 of 1

MOUNTING LOCATION:

Left top of glove box GL

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

TOOLS REQUIRED:

#T20 Torx driver (magnetic)

PART#: **75102-500**

MFG: **AUDI**

MODELS & YEARS:

TT 2000-2006

HARDWARE INCLUDED:

None

STEP #1

Open glove box door and remove the (3) screws on the top facing downward. Pull off the cover panel that faces the passenger door. It has (3) clips and pull out and back to remove. Remove the (3) lower exposed screws.

STEP #2

Loosen the molded cover beneath the cover panel to assist with pulling out the glove box. There are (2) screws below the outside of the glove box and above the tray below the glove box. (Here you may need an extension) Remove glove box and let sit on the floor, **DO NOT DISCONNECT WIRING.**

STEP #3

Loosen screws that hold the radio bezel on which is to the right of the radio cover. Pull down so that the mount fits between the bracket and screw hole, and that pin fits in the second hole. Screw in the screw for the radio bezel and replace glove box. Replace all screws in reverse order and reinstall cover panel on passenger side

STEP #4

Attach the phone holder to your InDash Mount.

INSTALLATION IS NOW COMPLETE... ENJOY YOUR NEW INDASH MOUNT...



Mounting Location of Screw.



Finished Install Picture



09-13-05